

RegO® SKL Advantage Series Long Stem Stainless Steel Globe Valves Repair Kits

RegO® Series Number	Repair Kit Number	Repair Kit Contents
SKL9402 Series	SKM009404-80AJ	(1) Gasket and (1) seat disc assembly
SKL9402 Series	SKM009408-80J	(2) Spring, belleville, (1) washer, live-loading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) packing, adapter
SKL9402 Series	SKL009404-Kit	(1) Gasket, (1) stem, (1) bonnet & tube assembly, (2) spring, belleville, (1) washer, live-
SKL9404 Series	SKM009408-80AJ	(1) Gasket and (1) seat disc assembly
SKL9404 Series	SKM009408-80J	(2) Spring, belleville, (1) washer, live-loading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) packing, adapter
SKL9404 Series	SKL009408-Kit	(1) Gasket, (1) stem, (1) bonnet & tube assembly, (2) spring, belleville, (1) washer, liveloading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) nut, stem, (1) ring, retaining, (1) packing, adapter, (1) nut, bonnet, (4) screw, (1) handwheel, (1) nut, hex, and (1) washer
SKL9406 Series	SKM009412-80AJ	(1) Gasket and (1) seat disc assembly
SKL9406 Series	SKM009408-80J	(2) Spring, belleville, (1) washer, live-loading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) packing, adapter
SKL9406 Series	SKL009404-Kit	(1) Gasket, (1) stem, (1) bonnet & tube assembly, (2) spring, belleville, (1) washer, liveloading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) nut, stem, (1) ring, retaining, (1) packing, adapter, (1) nut, bonnet, (4) screw, (1) handwheel, (1) nut, hex, and (1) washer
SKL9408 Series	SKM009408-80J	(1) Gasket and (1) seat disc assembly
SKL9408 Series	SKM009408-80J	(2) Spring, belleville, (1) washer, live-loading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) packing, adapter
SKL9408 Series	SKL009408-Kit	(1) Gasket, (1) stem, (1) bonnet & tube assembly, (2) spring, belleville, (1) washer, liveloading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) nut, stem, (1) ring, retaining, (1) packing, adapter, (1) nut, bonnet, (4) screw, (1) handwheel, (1) nut, hex, and (1) washer
SKL9412 Series	SKM009412-80J	(1) Gasket and (1) seat disc assembly
SKL9412 Series	SKM009412-80J	(2) Spring, belleville, (1) washer, live-loading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) packing, adapter
SKL9412 Series	SKL009412-Kit	(1) Gasket, (1) stem, (1) bonnet & tube assembly, (2) spring, belleville, (1) washer, liveloading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) nut, stem, (1) ring, retaining, (1) packing, adapter, (1) nut, bonnet, (4) screw, (1) handwheel, (1) nut, hex, and (1) washer
SKL9416 Series	SKM009416-80J	(1) Gasket and (1) seat disc assembly
SKL9416 Series	SKM009416-80J	(2) Spring, belleville, (1) washer, live-loading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) packing, adapter
SKL9416 Series	SKL009412-Kit	(1) Gasket, (1) stem, (1) bonnet & tube assembly, (2) spring, belleville, (1) washer, liveloading, (5) packing, bonnet, (4) packing, separator, (1) bearing, bonnet, (1) follower, gland, (1) nut, stem, (1) ring, retaining, (1) packing, adapter, (1) nut, bonnet, (4) screw, (1) handwheel, (1) nut, hex, and (1) washer